


Black Shoe Cleaner


Instruction Manual

Schuhreiniger schwarz
Nettoyeur de chaussures noir
Limpiazapatos negro
Netejasabates negre



Operation Instruction

1. Uncover the battery compartment then put 4 X 1.5V "AA" alkaline batteries inside the compartment by matching "+" and "-" mark on the batteries with those in the compartment. Put the cover back in place.
2. Low rotating speed – pressing switch for one time
- High rotating speed – pressing switch for the second time
- Stop rotating – pressing switch for the third time



Caution

1. Please use correct size and type of batteries.
2. When installing batteries, make sure battery polarities matching the polarity marks in compartment.
3. Take out batteries when you are not going to use the mechanism for a long time.
4. Don't mix old and new batteries.
5. Don't press the brush onto shoes or clothes strongly when cleaning.
6. Don't put the Cleaner into water or other liquid to avoid product damage or personal injury.